



Art No. NBS004 - NBS008

## Heavy Duty Security Cable with 4-Dial Combination Lock

### Specification:

- NoteGuard Security Cable
- Designed to secure most Notebooks, Projectors & LCD & Plasma Screens
- Easy to install
- Ideal theft deterrent
- Color: Black, White, Blue, Pink, Silver


### Package Contents:

- 1 x SecurityCable with 4-Dial Combination Lock

| Model Name | Color  | EAN Code      |
|------------|--------|---------------|
| NBS004     | Black  | 4052792000566 |
| NBS005     | White  | 4052792000573 |
| NBS006     | Blue   | 4052792000580 |
| NBS007     | Pink   | 4052792000597 |
| NBS008     | Silver | 4052792000603 |

### Packaging Information:

- Packing Dimension: mm
- Packing Weight: kg
- Carton Dimension: mm
- Carton Q'ty: pcs
- Carton Weight: kgs






Art No. NBS004 zu NBS008

## Heavy Duty Security Cable with 4-Dial Combination Lock

### Reset Combination:

1. The pre-set combination is 0-0-0-0.
2. In order to set your own combination, hold the lock and using a small flat-head screwdriver or similar object, push in (B) and rotate the reset screw 90° clockwise so that the screw's groove appears horizontal, then reset your own new combination.
3. Then rotate the reset screw 90° counter clock wise back to its original vertical position to save the new combination.
4. Record the combination in either the space provided at the end of this guide or another secure, easy-to-find place.



### Testing the Combination:

Before attaching the lock to your Notebook computer.

1. Turn the dials to disguise the combination.
2. Return to the combination you set.
3. Check that locking button depresses completely.

### STEP 1:

Loop the cable around a secure object.

### STEP 2:

Insert the lock into the computer slot then rotate (closewise) the lock to 90°. Release button (A) and mix number combination.

### STEP 3:

To open the lock, please use your own combination and press button (A) then rotate (anti-closewise) the lock to 90° to open the lock.

